

13345000	Ecostat	Ecostat 2001 Exposed Thermostatic Bath/Shower Mixer G ½	chrome	03/93 - 09/99
13345000	Ecostat	Ecostat 2001 Exposed Thermostatic Bath/Shower Mixer G ½	chrome	09/99 - 12/03
13345030	Ecostat	Ecostat 2001 Exposed Thermostatic Bath/Shower Mixer G ½	chrome/blue	04/95 - 09/99
13345030	Ecostat	Ecostat 2001 Exposed Thermostatic Bath/Shower Mixer G ½	chrome/blue	09/99 - 05/03
13345060	Ecostat	Ecostat 2001 Exposed Thermostatic Bath/Shower Mixer G ½	chrome/black	05/93 - 05/99
13345070	Ecostat	Ecostat 2001 Exposed Thermostatic Bath/Shower Mixer G ½	chrome/green	06/96 - 05/99
13345080	Ecostat	Ecostat 2001 Exposed Thermostatic Bath/Shower Mixer G ½	chrome/fine brass	04/95 - 05/99
13345090	Ecostat	Ecostat 2001 Exposed Thermostatic Bath/Shower Mixer G ½	chrome/gold-optic	03/93 - 09/99
13345090	Ecostat	Ecostat 2001 Exposed Thermostatic Bath/Shower Mixer G ½	chrome/gold-optic	09/99 - 12/03